

Article No., "Description", "Model Year", "Model Variant"
8003K4,"125 Duke 2011","2011","EU"
8003L4,"125 Duke 2012","2012","EU"
8003L5,"125 Duke 2012","2012","EU"
8003M4,"125 Duke 2012","2013","EU"
8026K4,"125 Duke 2011","2011","EU"
8026L4,"125 Duke 2012","2012","EU"
8026L5,"125 Duke 2012","2012","EU"
8103L4,"200 Duke 2012","2012","EU"
8103L5,"200 Duke 2012","2012","EU"
8103L6,"200 Duke 2012","2012","EU"
9703H6,"690 Enduro 2008","2008","EU"
9703I6,"690 Enduro 2009","2009","EU"
9703I8,"690 Enduro R 2009","2009","EU"
9703J6,"690 Enduro 2010","2010","EU"
9703J8,"690 Enduro R 2010","2010","EU"
9703K8,"690 Enduro R 2011","2011","EU"
9703L0,"690 Duke 2012","2012","EU"
9703L3,"690 Duke 2012","2012","EU"
9703L3C,"690 Duke 2012","2012","EU"
9703L4,"690 Duke 2012","2012","EU"
9703L4C,"690 Duke 2012","2012","EU"
9725D7,"640 Duke II 2004","2004","EU"
9725F7,"640 Duke II 2006","2006","EU"
9726D4,"640 Duke II 2004","2004","EU"
9726F4,"640 Duke II 2006","2006","EU"
9799G8,"690 Rally Factory Replica 2007","2007","EU"
9799H8,"690 Rally Factory Replica 2008","2008","EU"
9799I8,"690 Rally Factory Replica 2009","2009","EU"
9799J8,"690 Rally Factory Replica 2010","2010","EU"
9803D1,"950 Adventure 2004","2004","EU"
9803D3,"950 Adventure S 2004","2004","EU"
9803D4,"990 Superduke 2004","2004","EU"
9803D5,"950 Adventure 2004","2004","EU"
9803D6,"950 Adventure 2004","2004","EU"
9803D7,"990 Superduke 2004","2004","EU"
9803F1,"950 Supermoto 2006","2006","EU"
9803F3,"990 Adventure S 2006","2006","EU"
9803F4,"990 Super Duke 2006","2006","EU"
9803F5,"990 Adventure 2006","2006","EU"
9803F6,"990 Adventure 2006","2006","EU"
9803F7,"990 Super Duke 2006","2006","EU"
9803F8,"990 Super Duke 2006","2006","EU"
9803G0,"950 Supermoto 2007","2007","EU"
9803G1,"950 Supermoto R 2007","2007","EU"
9803G2,"950 Supermoto 2007","2007","EU"
9803G3,"990 Adventure S 2007","2007","EU"
9803G4,"990 Super Duke 2007","2007","EU"
9803G5,"990 Adventure 2007","2007","EU"
9803G6,"990 Adventure 2007","2007","EU"

9803G7,"990 Super Duke 2007","2007","EU"
9803G8,"990 Super Duke R 2007","2007","EU"
9803H0,"990 Supermoto 2008","2008","EU"
9803H1,"950 Supermoto R 2008","2008","EU"
9803H2,"990 Supermoto 2008","2008","EU"
9803H3,"990 Adventure S 2008","2008","EU"
9803H4,"990 Super Duke 2008","2008","EU"
9803H5,"990 Adventure 2008","2008","EU"
9803H6,"990 Adventure 2008","2008","EU"
9803H7,"990 Super Duke 2008","2008","EU"
9803H8,"990 Super Duke R 2008","2008","EU"
9803HW,"990 Super Duke 2008","2008","EU"
9803I0,"990 Supermoto 2009","2009","EU"
9803I1,"990 Supermoto R 2009","2009","EU"
9803I2,"990 Supermoto 2009","2009","EU"
9803I3,"990 Adventure R 2009","2009","EU"
9803I4,"990 Super Duke 2009","2009","EU"
9803I5,"990 Adventure 2009","2009","EU"
9803I6,"990 Adventure 2009","2009","EU"
9803I7,"990 Super Duke 2009","2009","EU"
9803I8,"990 Super Duke R 2009","2009","EU"
9803I9,"990 Supermoto T 2009","2009","EU"
9803IA,"990 Super Duke 2009","2009","EU"
9803IS,"990 Supermoto T 2009","2009","EU"
9803J0,"990 Supermoto T 2010","2010","EU"
9803J1,"990 Supermoto R 2010","2010","EU"
9803J2,"990 Supermoto T 2010","2010","EU"
9803J3,"990 Adventure R 2012","2010","EU"
9803J4,"990 Super Duke 2010","2010","EU"
9803J5,"990 Adventure 2010","2010","EU"
9803J6,"990 Adventure 2010","2010","EU"
9803J7,"990 Super Duke 2010","2010","EU"
9803J8,"990 Super Duke R 2010","2010","EU"
9803J9,"990 Supermoto T 2010","2010","EU"
9803JB,"990 Adventure 2010","2010","EU"
9803K0,"990 Supermoto T 2011","2011","EU"
9803K1,"990 Supermoto R 2011","2011","EU"
9803K2,"990 Supermoto T 2011","2011","EU"
9803K3,"990 Adventure R 2011","2011","EU"
9803K4,"990 Super Duke 2011","2011","EU"
9803K5,"990 Adventure 2011","2011","EU"
9803K6,"990 Adventure 2011","2011","EU"
9803K8,"990 Super Duke R 2011","2011","EU"
9803K9,"990 Supermoto T 2011","2011","EU"
9803KA,"990 Supermoto T 2011","2011","EU"
9803KB,"990 Adventure 2011","2011","EU"
9803KE,"990 Adventure 2011","2011","EU"
9803KF,"990 Adventure 2011","2011","EU"
9803KG,"990 Adventure 2011","2011","EU"
9803KH,"990 Adventure R 2011","2011","EU"

9803L3,"990 Adventure R 2012","2012","EU"
9803L5,"990 Adventure 2012","2012","EU"
9803L6,"990 Adventure 2012","2012","EU"
9803L8,"990 Super Duke R 2012","2012","EU"
9803LB,"990 Adventure 2012","2012","EU"
9903G1,"990 Super Duke 2007","2007","EU"
9903H0,"1190 RC8 2008","2008","EU"
9903H7,"1190 RC8 2008","2008","EU"
9903I0,"1190 RC8 2009","2009","EU"
9903I2,"1190 RC8 R 2009","2009","EU"
9903I3,"1190 RC8 2009","2009","EU"
9903I4,"1190 RC8 2009","2009","EU"
9903I7,"1190 RC8 2009","2009","EU"
9903I8,"1190 RC8 2009","2009","EU"
9903IA,"1190 RC8 2009","2009","EU"
9903IR,"1190 RC8 2009","2009","EU"
9903J0,"1190 RC8 2010","2010","EU"
9903J2,"1190 RC8 R 2010","2010","EU"
9903J4,"1190 RC8 2010","2010","EU"
9903J7,"1190 RC8 2010","2010","EU"
9903K0,"1190 RC8 2011","2011","EU"
9903K1,"1190 RC8 R 2011","2011","EU"
9903K3,"1190 RC8 R 2011","2011","EU"
9903KT,"1190 RC8 R Track 2011","2010","EU"
9903L1,"1190 RC8 R 2012","2012","EU"
9903L3,"1190 RC8 R 2012","2012","EU"
9903LT,"1190 RC8 R Track 2012","2012","EU"
972537,"640 Duke II 2003","2003","EU"
972634,"640 Duke II 2003","2003","EU"
972639,"640 Duke II 2003","2003","EU"
980331,"950 Adventure 2003","2003","EU"
980333,"950 Adventure S 2003","2003","EU"
980335,"950 Adventure 2003","2003","EU"
9803E3,"950 Adventure S 2005","2005","EU"
9726E4,"640 Duke II 2005","2005","EU"
9803E4,"990 Super Duke 2005","2005","EU"
9803E5,"950 Adventure 2005","2005","EU"
9803E6,"950 Adventure 2005","2005","EU"
9725E7,"640 Duke II 2005","2005","EU"
9803E7,"990 Super Duke 2005","2005","EU"
F4003N4,"125 Duke 2014","2014","EU"
F4003N5,"125 Duke 2014","2014","EU"
F4003N6,"125 Duke 2014","2014","EU"
F4003N7,"125 Duke 2014","2014","EU"
F4003O1,"125 Duke 2015","2015","EU"
F4003O2,"125 Duke 2015","2015","EU"
F4003O2B,"125 Duke 2015","2015","EU"
F4003O3,"125 Duke 2015","2015","EU"
F4003O4,"125 Duke 2015","2015","EU"
F4003P1,"125 Duke 2016","2016","EU"

F4003P2,"125 Duke 2016","2016","EU"
F4003P3,"125 Duke 2016","2016","EU"
F4003P4,"125 Duke 2016","2016","EU"
F4003Q1,"125 Duke 2017","2017","EU"
F4003Q2,"125 Duke 2017","2017","EU"
F4003Q3,"125 Duke 2017","2017","EU"
F4003Q4,"125 Duke 2017","2017","EU"
F4003R1,"125 Duke 2018","2018","EU"
F4003R2,"125 Duke 2018","2018","EU"
F4003R3,"125 Duke 2018","2018","EU"
F4003R4,"125 Duke 2018","2018","EU"
F4003S1,"125 Duke 2019","2019","EU"
F4003S1B,"125 Duke 2019","2019","EU"
F4003S2,"125 Duke 2019","2019","EU"
F4003S2B,"125 Duke 2019","2019","EU"
F4003S3,"125 Duke 2019","2019","EU"
F4003S4,"125 Duke 2019","2019","EU"
F4003T1,"125 Duke 2020","2020","EU"
F4003T1B,"125 Duke 2020","2020","EU"
F4003T2,"125 Duke 2020","2020","EU"
F4003T2B,"125 Duke 2020","2020","EU"
F4003T3,"125 Duke 2020","2020","EU"
F4003T4,"125 Duke 2020","2020","EU"
F4003U1,"125 Duke 2021","2021","EU"
F4003U2,"125 Duke 2021","2021","EU"
F4003U3,"125 Duke 2021","2021","EU"
F4003U4,"125 Duke 2021","2021","EU"
F4103N1,"200 Duke 2014","2014","EU"
F4103N2,"200 Duke 2014","2014","EU"
F4103N4,"200 Duke 2014","2014","EU"
F4103N5,"200 Duke 2014","2014","EU"
F4103N6,"200 Duke 2014","2014","EU"
F4103N7,"200 Duke 2014","2014","EU"
F4103N8,"200 Duke 2014","2014","EU"
F4103N9,"200 Duke 2014","2014","EU"
F4103O1,"200 Duke 2015","2015","EU"
F4103O2,"200 Duke 2015","2015","EU"
F4103P1,"200 Duke 2016","2016","EU"
F4103P2,"200 Duke 2016","2016","EU"
F4103Q1,"200 Duke 2017","2017","EU"
F4103Q2,"200 Duke 2017","2017","EU"
F4103Q3,"200 Duke 2017","2017","EU"
F4103R1,"200 Duke 2018","2018","EU"
F4103R2,"200 Duke 2018","2018","EU"
F4103R3,"200 Duke 2018","2018","EU"
F4103S1,"200 Duke 2019","2019","EU"
F4103S2,"200 Duke 2019","2019","EU"
F4103S3,"200 Duke 2019","2019","EU"
F4103S6,"200 Duke 2019","2019","EU"
F4103S7,"200 Duke 2019","2019","EU"

F4103T2,"200 Duke 2020","2020","EU"
F4103T2L,"200 Duke 2020","2020","EU"
F4103T3,"200 Duke 2020","2020","EU"
F4103T3L,"200 Duke 2020","2020","EU"
F4103T5,"200 Duke 2020","2020","EU"
F4103T5L,"200 Duke 2020","2020","EU"
F4103T6,"200 Duke 2020","2020","EU"
F4103T6L,"200 Duke 2020","2020","EU"
F4103T7,"200 Duke 2020","2020","EU"
F4103T7L,"200 Duke 2020","2020","EU"
F4103U2,"200 Duke 2021","2021","EU"
F4103U2L,"200 Duke 2021","2021","EU"
F4103U3,"200 Duke 2021","2021","EU"
F4103U3L,"200 Duke 2021","2021","EU"
F4103U5,"200 Duke 2021","2021","EU"
F4103U5L,"200 Duke 2021","2021","EU"
F4103U6,"200 Duke 2021","2021","EU"
F4103U6L,"200 Duke 2021","2021","EU"
F4103U7,"200 Duke 2021","2021","EU"
F4103U7L,"200 Duke 2021","2021","EU"
F4203O1,"250 Duke 2015","2015","EU"
F4203O2,"250 Duke 2015","2015","EU"
F4203P1,"250 Duke 2016","2016","EU"
F4203P2,"250 Duke 2016","2016","EU"
F4203Q1,"250 Duke 2017","2017","EU"
F4203Q2,"250 Duke 2017","2017","EU"
F4203Q3,"250 Duke 2017","2017","EU"
F4203Q4,"250 Duke 2017","2017","EU"
F4203R1,"250 Duke 2018","2018","EU"
F4203R2,"250 Duke 2018","2018","EU"
F4203R3,"250 Duke 2018","2018","EU"
F4203R4,"250 Duke 2018","2018","EU"
F4203S1,"250 Duke 2019","2019","EU"
F4203S2,"250 Duke 2019","2019","EU"
F4203S3,"250 Duke 2019","2019","EU"
F4203S4,"250 Duke 2019","2019","EU"
F4203S6,"250 Duke 2019","2019","EU"
F4203S7,"250 Duke 2019","2019","EU"
F4203S8,"250 Duke 2019","2019","EU"
F4203S9,"250 Duke 2019","2019","EU"
F4203T1,"250 Duke 2020","2020","EU"
F4203T1L,"250 Duke 2020","2020","EU"
F4203T2,"250 Duke 2020","2020","EU"
F4203T2L,"250 Duke 2020","2020","EU"
F4203T3,"250 Duke 2020","2020","EU"
F4203T3L,"250 Duke 2020","2020","EU"
F4203T4,"250 Duke 2020","2020","EU"
F4203T4L,"250 Duke 2020","2020","EU"
F4203U1,"250 Duke 2021","2021","EU"
F4203U1L,"250 Duke 2021","2021","EU"

F4203U2,"250 Duke 2021","2021","EU"
F4203U2L,"250 Duke 2021","2021","EU"
F4303N5,"390 Duke 2014","2014","EU"
F4303N6,"390 Duke 2014","2014","EU"
F4303N7,"390 Duke 2014","2014","EU"
F4303N8,"390 Duke 2014","2014","EU"
F4303O1,"390 Duke 2015","2015","EU"
F4303O2,"390 Duke 2015","2015","EU"
F4303O3,"390 Duke 2015","2015","EU"
F4303O4,"390 Duke 2015","2015","EU"
F4303P1,"390 Duke 2016","2016","EU"
F4303P2,"390 Duke 2016","2016","EU"
F4303P3,"390 Duke 2016","2016","EU"
F4303P4,"390 Duke 2016","2016","EU"
F4303Q1,"390 DUKE 2017","2017","EU"
F4303Q2,"390 DUKE 2017","2017","EU"
F4303Q3,"390 DUKE 2017","2017","EU"
F4303Q4,"390 DUKE 2017","2017","EU"
F4303R1,"390 Duke 2018","2018","EU"
F4303R2,"390 Duke 2018","2018","EU"
F4303R3,"390 Duke 2018","2018","EU"
F4303R4,"390 Duke 2018","2018","EU"
F4303S1,"390 Duke 2019","2019","EU"
F4303S1B,"390 Duke 2019","2019","EU"
F4303S2,"390 Duke 2019","2019","EU"
F4303S2B,"390 Duke 2019","2019","EU"
F4303S3,"390 Duke 2019","2019","EU"
F4303S4,"390 Duke 2019","2019","EU"
F4303T1,"390 Duke 2020","2020","EU"
F4303T1B,"390 Duke 2020","2020","EU"
F4303T2,"390 Duke 2020","2020","EU"
F4303T2B,"390 Duke 2020","2020","EU"
F4303T3,"390 Duke 2020","2020","EU"
F4303T3L,"390 Duke 2020","2020","EU"
F4303T4,"390 Duke 2020","2020","EU"
F4303T4L,"390 Duke 2020","2020","EU"
F4303U1,"390 Duke 2021","2021","EU"
F4303U2,"390 Duke 2021","2021","EU"
F4303U3,"390 Duke 2021","2021","EU"
F4303U3L,"390 Duke 2021","2021","EU"
F4303U4,"390 Duke 2021","2021","EU"
F4303U4L,"390 Duke 2021","2021","EU"
F4303U5,"390 Duke 2021","2021","EU"
F4303U6,"390 Duke 2021","2021","EU"
F5003N1,"RC 125 2014","2014","EU"
F5003N3,"RC 125 2014","2014","EU"
F5003O1,"RC 125 2015","2015","EU"
F5003O2,"RC 125 2015","2015","EU"
F5003P1,"RC 125 2016","2016","EU"
F5003P2,"RC 125 2016","2016","EU"

F5003Q1,"RC 125 2017","2017","EU"
F5003Q2,"RC 125 2017","2017","EU"
F5003R1,"RC 125 2018","2018","EU"
F5003R2,"RC 125 2018","2018","EU"
F5003S1,"RC 125 2019","2019","EU"
F5003S1B,"RC 125 2019","2019","EU"
F5003S2,"RC 125 2019","2019","EU"
F5003T1,"RC 125 2020","2020","EU"
F5003T1B,"RC 125 2020","2020","EU"
F5003T2,"RC 125 2020","2020","EU"
F5003V1,"RC 125 2022","2022","EU"
F5003V1B,"RC 125 2022","2022","EU"
F5003V2,"RC 125 2022","2022","EU"
F5003V2B,"RC 125 2022","2022","EU"
F5003V3,"RC 125 2022","2022","EU"
F5003V4,"RC 125 2022","2022","EU"
F5103N3,"RC 200 2014","2014","EU"
F5103N4,"RC 200 2014","2014","EU"
F5103N6,"RC 200 2014","2014","EU"
F5103O1,"RC 200 2015","2015","EU"
F5103P1,"RC 200 2016","2016","EU"
F5103Q1,"RC 200 2017","2017","EU"
F5103R1,"RC 200 2018","2018","EU"
F5103S1,"RC 200 2019","2019","EU"
F5103T1,"RC 200 2020","2020","EU"
F5103T1L,"RC 200 2020","2020","EU"
F5103V1,"RC 200 2022","2022","EU"
F5103V1L,"RC 200 2022","2022","EU"
F5103V2,"RC 200 2022","2022","EU"
F5103V2L,"RC 200 2022","2022","EU"
F5203O1,"RC 250 2015","2015","EU"
F5203P1,"RC 250 2016","2016","EU"
F5203Q1,"RC 250 2017","2017","EU"
F5203S1,"RC 250 2019","2019","EU"
F5203U5,"250 Adventure 2021","2021","EU"
F5203U5B,"250 Adventure 2021","2021","EU"
F5203U6,"250 Adventure 2021","2021","EU"
F5203U6B,"250 Adventure 2021","2021","EU"
F5203U7,"250 Adventure 2021","2021","EU"
F5203U7L,"250 Adventure 2021","2021","EU"
F5203U8,"250 Adventure 2021","2021","EU"
F5203U8L,"250 Adventure 2021","2021","EU"
F5303N1,"RC 390 2014","2014","EU"
F5303N3,"RC 390 2014","2014","EU"
F5303O1,"RC 390 2015","2015","EU"
F5303O2,"RC 390 2015","2015","EU"
F5303P1,"RC 390 2016 (Euro 4)","2016","EU"
F5303P2,"RC 390 2016","2016","EU"
F5303Q1,"RC 390 2017","2017","EU"
F5303Q2,"RC 390 2017","2017","EU"

F5303R1,"RC 390 2018","2018","EU"
F5303R2,"RC 390 2018","2018","EU"
F5303R9,"RC 390 R 2018","2018","EU"
F5303S1,"RC 390 2019","2019","EU"
F5303S1B,"RC 390 2019","2019","EU"
F5303S2,"RC 390 2019","2019","EU"
F5303T1,"RC 390 2020","2020","EU"
F5303T2,"RC 390 2020","2020","EU"
F5303T2L,"RC 390 2020","2020","EU"
F5303T5,"390 Adventure 2020","2020","EU"
F5303T5B,"390 Adventure 2020","2020","EU"
F5303T6,"390 Adventure 2020","2020","EU"
F5303T6B,"390 Adventure 2020","2020","EU"
F5303T7,"390 Adventure 2020","2020","EU"
F5303T7L,"390 Adventure 2020","2020","EU"
F5303T8,"390 Adventure 2020","2020","EU"
F5303T8L,"390 Adventure 2020","2020","EU"
F5303T9,"RC 390 R 2020","2020","EU"
F5303TA,"390 Adventure 2020","2020","EU"
F5303U1,"RC 390 2021","2021","EU"
F5303U1B,"RC 390 2021","2021","EU"
F5303U2,"RC 390 2021","2021","EU"
F5303U2L,"RC 390 2021","2021","EU"
F5303U5,"390 Adventure 2021","2021","EU"
F5303U5B,"390 Adventure 2021","2021","EU"
F5303U6,"390 Adventure 2021","2021","EU"
F5303U6B,"390 Adventure 2021","2021","EU"
F5303U7,"390 Adventure 2021","2021","EU"
F5303U7L,"390 Adventure 2021","2021","EU"
F5303U8,"390 Adventure 2021","2021","EU"
F5303U8L,"390 Adventure 2021","2021","EU"
F5303V1,"RC 390 2022","2022","EU"
F5303V1B,"RC 390 2022","2022","EU"
F5303V2,"RC 390 2022","2022","EU"
F5303V2B,"RC 390 2022","2022","EU"
F5303V3,"RC 390 2022","2022","EU"
F5303V3L,"RC 390 2022","2022","EU"
F5303V4,"RC 390 2022","2022","EU"
F5303V4L,"RC 390 2022","2022","EU"
F5399N1,"RC 390 2014","2014","EU"
F5399O1,"RC 390 ADAC CUP 2015","2015","EU"
F5399P1,"RC 390 CUP 2016","2016","EU"
F5399Q1,"RC 390 CUP 2017","2017","EU"
F8003M4,"125 Duke 2013","2013","EU"
F8003M5,"125 Duke 2013","2013","EU"
F8003M6,"125 Duke 2013","2013","EU"
F8003M7,"125 Duke 2013","2013","EU"
F8003N1,"RC 125 2014","2014","EU"
F8003N4,"125 Duke 2014","2014","EU"
F8003N5,"125 Duke 2014","2014","EU"

F8003N6,"125 Duke 2014","2014","EU"
F8003N7,"125 Duke 2014","2014","EU"
F8103M4,"200 Duke 2013","2013","EU"
F8103M5,"200 Duke 2013","2013","EU"
F8103M6,"200 Duke 2013","2013","EU"
F8103M7,"200 Duke 2013","2013","EU"
F8103MA,"200 Duke 2013","2013","EU"
F8103MB,"200 Duke 2013","2013","EU"
F8103N4,"200 Duke 2014","2014","EU"
F8103N5,"200 Duke 2014","2014","EU"
F8103N6,"200 Duke 2014","2014","EU"
F8103N7,"200 Duke 2014","2014","EU"
F8303M5,"390 Duke 2013","2013","EU"
F8303M7,"390 Duke 2013","2013","EU"
F8303M7C,"390 Duke 2013","2013","EU"
F8303N1,"RC 390 2014","2014","EU"
F8303N3,"RC 390 2014","2014","EU"
F8303N5,"390 Duke 2014","2014","EU"
F8303N7,"390 Duke 2014","2014","EU"
F9703M0,"690 Duke 2013","2013","EU"
F9703M3,"690 Duke 2013","2013","EU"
F9703M4,"690 Duke 2013","2013","EU"
F9703N3,"690 Duke 2014","2014","EU"
F9703N4,"690 Duke 2014","2014","EU"
F9703O3,"690 Duke 2015","2015","EU"
F9703O4,"690 Duke 2015","2015","EU"
F9703P3,"690 Duke 2016","2016","EU"
F9703P4,"690 Duke 2016","2016","EU"
F9703Q3,"690 Duke 2017","2017","EU"
F9703Q4,"690 Duke 2017","2017","EU"
F9703R4,"690 Duke 2018","2018","EU"
F9703S4,"690 Duke 2019","2019","EU"
F9803M8,"990 Super Duke R 2013","2013","EU"
F9903M1,"1190 RC8 R 2013","2013","EU"
F9903M3,"1190 RC8 R 2013","2013","EU"
F9903N1,"1190 RC8 R 2014","2014","EU"
F9903N2,"1290 Super Duke R 2014","2014","EU"
F9903N9,"1290 Super Duke R 2014","2014","EU"
F9903O1,"1190 RC8 R 2015","2015","EU,GB"
F9903O2,"1290 Super Duke R 2015","2015","EU"
F9903O9,"1290 Super Duke R 2015","2015","EU"
F9903P0,"1290 Super Duke R Special Edition 2016","2016","EU"
F9903P1,"1190 RC8 R 2016","2016","EU,GB"
F9903P2,"1290 Super Duke R 2016","2016","EU"
F9903P3,"1290 Super Duke GT 2016","2016","EU"
F9903P9,"1290 Super Duke R 2016","2016","EU"
F9903PF,"1290 Super Duke GT 2016","2016","EU"
F9903Q2,"1290 Super Duke R 2017","2017","EU"
F9903Q9,"1290 Super Duke R 2017","2017","EU"
F9903QE,"1290 Super Duke GT 2017","2017","EU"

F9903QF,"1290 Super Duke GT 2017","2017","EU"
F9903QG,"1290 Super Duke GT 2017","2017","EU"
F9903QH,"1290 Super Duke GT 2017","2017","EU"
F9903QL,"1290 Super Duke R 2017","2017","EU"
F9903QM,"1290 Super Duke R 2017","2017","EU"
F9903R2,"1290 SUPER DUKE R 2018","2018","EU"
F9903R9,"1290 SUPER DUKE R 2018","2018","EU"
F9903RE,"1290 SUPER DUKE GT 2018","2018","EU"
F9903RF,"1290 SUPER DUKE GT 2018","2018","EU"
F9903S2,"1290 Super Duke R 2019","2019","EU"
F9903S9,"1290 Super Duke R 2019","2019","EU"
F9903SE,"1290 Super Duke GT 2019","2019","EU"
F9903SF,"1290 Super Duke GT 2019","2019","EU"
F9903TE,"1290 Super Duke GT 2020","2020","EU"
F9903TF,"1290 Super Duke GT 2020","2020","EU"
F9903UE,"1290 Super Duke GT 2021","2021","EU"
F9903UF,"1290 Super Duke GT 2021","2021","EU"
F9903VF,"1290 Super Duke GT 2022","2022","EU"
F9975UF,"1290 Super Duke GT 2021","2021","EU"
F9986UF,"1290 Super Duke GT 2021","2021","EU"
F9987UF,"1290 Super Duke GT 2021","2021","EU"